#### **MILLIMETERS**

# **GRAPH TECH QUICK SIZING GUIDE**

**INCHES** 

Use this guide to determine the size of your current parts to assist you in finding a correct replacement. For a complete listing of over 300 nuts, saddles and bridge pins, please visit our website at www.graphtech.com

Products illustrated are actual size.

#### **IMPORTANT NOTE!**

To ensure accurate printing, please print in Adobe Acrobat Reader, set your printer settings to 100%, and make sure no special printing options are selected.


#### **UNDERSTANDING GRAPH TECH PART NUMBERS**


Packaged (P) or Bulk (B) Part Number


Brand: Q=TUSQ®; S=String Saver™; T= Black TUSQ® XL; G=String Saver™ Classic Steel N=GHOST e.g. PS-8000-00 = Packaged String Saver Saddles for Import Strat

# **ACOUSTIC, ELECTRIC & BASS NUTS**

To size a nut, measure length, width, height, and the E to E string spacing







5000-00 Strat Nut



#### **ACOUSTIC SADDLES**

To size a saddle, measure length, width, and height.



9000-00 Acoustic Blank 1/8"Saddle




9110-00 Acoustic Compensated Martin Saddle



9280-C0 Acoustic Compensated Saddle

#### **BRIDGE PINS**

To size bridge pins, measure the diameter at the top of the shank, just below the collar.














# MILLIMETERS


# **ELECTRIC SADDLES**


















Vintage Tele









### **BRIDGES** \*\*\*not to scale\*\*\*

## **Tune-o-matic Measuring Guide**



	String spread	Saddle radius	Post spacing	Post threads
Bridge	2 – 1/16"	12"	2.920"	M8 X 1.25
	52.4 mm	305 mm	74 mm	M8 X 1.25
Tailpiece	2 -1/16"	n/a	3.210"	M8 X 1.25
	52 4 mm	n/a	82	M8 X 1 25

## **Wraparound Measuring Guide**



	String spread	Saddle radius	Post spacing	Post threads
Bridge	2 – 1/16"	12"	3.224"	5/16`-24UNF
	52.4 mm	305 mm	82 mm	5/16`-24UNF









